External Charger and Charger Port Conversion Kit

Installation Instructions

Step 1: Remove the footplate and disconnect the wiring harness from the battery pack.

Step 2: Remove the dashboard from the scooter body.

Step 3: Disconnect the original charger's **black, white, and green wires** from the original charger port.

Step 4: Remove the original charger's two LEDs from the dashboard.

Step 5: Check the original charger's **red and black wires** to determine whether they are connected to the corresponding **red and black wires** of the wiring harness. If the wiring colors do not match, mark the wiring harness wires with tape labeled **"Red"** and **"Black"** to identify their correct connections. Then disconnect the charger's red and black wires from the wiring harness.

Step 6: Remove the bolts securing the original charger to the scooter body, then remove the charger.

Step 7: Remove the original charger port from the dashboard.

Step 8: Install the new charger port in the dashboard.

Step 9: Connect the new charger port's wires to the wiring harness, matching **red to red** and **black to black**.

Step 10: Reinstall the dashboard.

Step 11: Reconnect the wiring harness to the battery pack, then reinstall the footplate.